

Carter Gear Parts

Part No.	No. Per Gear	Description
401	2	Shaft Nut
402*	2	Locking Washer
403*	2	Gland Bush
404*	2	Gland Bush 'O' Ring
405	2	Input and Output Shaft Journal Bearing
406*	2	Gland Cover Paper Packing
407	1	Output Cover
409	1	Valveshaft
411	2	Thrust Bearing
412	1	Body
413*	1	Pump Delivery Block Fibre Washer
414	1	Pump Delivery Block Plug
415*	1	Pressure Port 'O' Ring
416	1	Pressure Port Plug
418	1	Breather Plug
419	2	Cover Plate
420	1	Slide Block
421	2	Cowl Distance Piece Screw
422	4	Washer
423	4	Cowl Rubber Grommet
424	2	Cowl Distance Piece
425	1	Input Rotation Indicator Plate
426	2	Input Rotation Indicator Plate Screw
427*	2	Input and Output Cover Paper Packing
	12	
428	F10, F12	Input and Output Cover Hexagon Head Screw
	16	
	F13, F14	
429	1	Input Cover
430	1	Fan
431*	4	Cover Plate Copper Washer
432	4	Cover Plate Socket Head Screw
433*	2	Gland Cover Oil Seals
	8	
	F10	
434	12	Gland Cover Socket Head Cap Screw
	F12, F13	
	F14	
435	2	Gland Cover
436	2	Cowl Support Screw
437	2	Cowl Support
438	1	Cowl
439	1	Nameplate
440	4	Nameplate Screw
442	1	Filter Holder Locking Nut (F10-F12-F13 Only)
443*	1	Filter Holder Fibre Washer
	1	
444*	F10, F12	Drain Plug Fibre Washer

	2	
	F13, F14	
	1	
445	F10, F12	Drain Plug
	2	
	F13, F14	
446	2	Filter Cover Socket Head Cap Screw
447	2	Filter Cover Spring Washer
448	1	Filter Holder
449	2	Filter Holder Socket Head Cap Screw
450*	2	Pump Delivery Block 'O' Ring
451	1	Filter Holder Screw (F10__F12__F13 Only)
452	4	Pump Delivery Block Somet Head Cap Screw
453	1	Pump Delivery Block
454*	2	Oil Filler Plug Fibre Washer
455	2	Oil Filler Plug
456	1	Blank Control Cover
457	4	Control Covers Socket Head Cap Screw
458*	2	Control Covers Paper Packing
459	2	Non-Return Valve Seat
460*	4	Non-Return Valve Seat 'O' Ring
461	2	Non-Return Valve Ball
462	2	Non-Return Valve Spring
463	2	Non-Return Valve Stop (F12__F13__F14 Only)
464	2	Ball Valve Stop (F10 Only)
465	2	Port Cover
471	1	Handwheel Taper Pin
472	1	Handwheel
473	4	Port Cover Socket Head Cap Screw
474	2	Oval Flange Socket Head Cap Screw
475	1	Oval Flange
476	1	Accumulator Spring
477*	2	Oval Flange 'O' Ring
481	1	Accumulator Shaft Pin
482	1	Accumulator Shaft Collar
483	1	Filter Holder Pin
485*	1	Filter Cover 'O' Ring (F10__F12 Only)
486	1	Filter
487	1	Filter Spring
488	1	Filter Cover
489*	1	Filter Cover Paper Packing (F13__F14 Only)
490	1	Filter Holder Screw (F14 Only)
491	2	Filter Holder Screw 'O' Ring (F14 Only)
492	1	Ritespeed' Cartridge Assembly
	6	
493	F10, F12	Ritespeed' Cartridge Socket Head Cap Screw
	8	
	F13, F14	
494*	1	Ritespeed' Cartridge Paper Packing
495	1	Ritespeed' Case
496	1	Ritespeed' Case Oil Filler and Breather Plug
497*	1	Oil Filler and Breather Plug Fibre Washer
498	4	Nameplate Rivet

499	1	Nameplate
	6	
500	F10, F12	Ritespeed' Case Hexagon Head Screw
	8	
	F13, F14	
501	2	Output Cover Socket Head Cap Screw
502	1	Output Shaft__For Gears Fitted With Ritespeed Only
503	1	Pinion Key
504	1	Ritespeed' 1st Reduction Wheel
505	1	Ritespeed' 1st Reduction Pinion
506	2	Oil Drain Plug
507*	2	Oil Drain Plug Fibre Washer
508*	2	Oil Level Plug Fibre Washer
509	2	Oil Level Plug
510*	1	Ritespeed' Oil Seal
511*	1	Ritespeed' Cartridge Cover Paper Packing

* Parts Normally Recommended To be Stocked And Fitted By Users

Sub Assemblies

Due to the selective method of assembly, the parts listed below are not normally supplied other than in the Sub-Assemblies listed below

Part No.	No. Per Ass'y	Description	No. Of Assb's Per Gear
		Output Shaft Assembly	
408	1	Output Shaft	1
410	7	Piston	
		Input Shaft Assembly	
441	1	Input Shaft	1
410	7	Piston	
		Make Up Pump Assembly	
417	1	Pump Ram	1
480	1	Pump Body	
		Accumulator Assembly	
478	1	Accumulator Piston	
479	1	Accumulator	1
484*	1	Accumulator Shaft 'O' Ring	

Carter F Type Parts

