



Tipo - Type

Dimensioni - Dimensions

Tipo - Type	Poli Poles	Estremità albero - Shaft Extension										Flangia B5 - B5 Flange										Flangia B14 - B14 Flange									
		H	A	B	C	AB	BB	K	D	E	F	GA	M	N	P	S	T	LA	M	N	P	S	T								
MA 63	2 - 8	63	100	80	40	120	100	7	11	23	4	12,5	115	95	140	9	3	10	75	60	90	M 5	2,5								
MA 71	2 - 8	71	112	90	45	136	110	7	14	30	5	16	130	110	160	9	3,5	10	85	70	105	M 6	2,5								
MA 80	2 - 8	80	125	100	50	155	125	9	19	40	6	21,5	165	130	200	11	3,5	12	100	80	120	M 6	3								
MA 90	2 - 8	90	140	100	56	174	155	9	24	50	8	27	165	130	200	11	3,5	12	115	95	140	M 8	3								
MA 100	2 - 8	100	160	140	63	194	180	11	28	60	8	31	215	180	250	14	4	14	130	110	160	M 8	3,5								
MA 112	2 - 8	112	190	140	70	224	180	11	28	60	8	31	215	180	250	14	4	14	130	110	160	M 8	3,5								
MA 132	2 - 8	132	216	140	89	252	226	11	38	80	10	41	265	230	300	14	4	14	130	110	160	M 8	3,5								
A 4C 160	2 - 8	160	254	210	108	296	296	14,5	42	110	12	45	300	250	350	18	5	15	300	250	350	M 5	15								
A 4C 180	2 - 4	180	279	241	121	321	283	14,5	48	110	14	51,5	300	250	350	18	5	15	300	250	350	M 6	14								
A 4C 200	2 - 8	200	318	305	133	360	347	18,5	55	110	16	59	350	300	400	18	5	15	350	300	400	M 6	15								
A 4C 225	4 - 8	225	356	286	149	405	360	18,5	60	140	18	64	400	350	450	18	5	16	400	350	450	M 8	16								
A 4C 250	2	250	406	349	168	465	406	22	60	140	18	64	500	450	550	18	5	18	500	450	550	M 8	18								
A 4C 280	2	280	457	368	190	540	480	24	65	140	18	69	500	450	550	18	5	18	500	450	550	M 8	18								
A 4C 315	2	315	508	419	216	590	470	28	75	140	20	79,5	600	550	660	22	6	22	600	550	660	M 8	22								
B 4C 315	2	315	315	457	216	590	520	27	65	140	18	69	600	550	660	22	6	22	600	550	660	M 8	22								
	2								80	170	22	85	600	550	660	22	6	22	600	550	660	M 8	22								
	2								65	140	18	69	600	550	660	22	6	22	600	550	660	M 8	22								
	2								70	140	20	74,5	600	550	660	22	6	22	600	550	660	M 8	22								
	2								90	170	25	95	600	550	660	22	6	22	600	550	660	M 8	22								